

SPACE COWBOY ASSEMBLY GUIDE

The Xtracycle Space Cowboy is a small spacer intended to increase the stability of the KickBack LT2 kickstand. It can either be installed with a new KickBack or retrofitted to a Kickback that is already installed on the bike.



The Space Cowboy can be installed on a new Kickback by simply sliding it over the top of the left leg of the KickBack, before installing the KickBack on the bike.



If you are retrofitting a Space Cowboy to a KickBack that is already installed on a bike:

- Loosen the nuts and bolts that attach the KickBack to the bike.
- Slide the Space Cowboy onto the top of the left leg of the KickBack body as show.
- Re-tighten the attachment bolts and nuts.

Note: for more information on KickBack installation and adjustment, refer to the KickBack LT2 Assembly Guide.



Warranty

Xtracycle Space Cowboys are guaranteed to be free from manufacturing defects for one (1) year from the original date of purchase. This warranty applies only to the original buyer and is not transferable. This warranty does not cover damage from use of this product outside of its intended range or that resulting from modification or neglect. It also does not cover wear and tear resulting from the normal use of the product. Please contact your Xtracycle dealer if you believe you have a warranty claim.