

XTRACYCLE®



PORTERRACK 
COMPATIBLE

- INSTRUCTIONS
- WARRANTY
- SAFETY PRECAUTIONS

WARRANTY

PorterRacks are guaranteed to be free from manufacturing defects for one (1) year from the original date of purchase. This warranty applies only to the original buyer and is not transferable. This warranty does not cover damage from use of this product outside of its intended range or that resulting from modification or neglect. It also does not cover wear and tear resulting from the normal use of the product. Please contact your Xtracycle dealer if you believe you have a warranty claim.

PORTERRACK INSTALLATION INSTRUCTIONS

- 1 Determine the appropriate mounting holes for your PorterRack by holding it up against the head tube bosses.



- 2 Insert the four (4) bolts with locking washers into the appropriate mounting holes.



- 3 Attach the 15mm spacers to the ends of the M6 bolts while the PorterRack is in place against the head tube bosses. (Note: it may be helpful to have an assistant hold the PorterRack.)



- 4 The brake, derailleur, and electric cables should be routed through the middle of the top and bottom mounting bolts.



- 5 Thread in all four bolts smoothly and evenly, alternating in a criss-cross pattern. Tighten bolts to 6-10 N-m



- 6 Your PorterRack is now ready for use.



-  **WARNING:** Before each ride, check tightness of all hardware - push and pull on all elements of U-Tubes to identify any loose hardware. Listen for rattles or feel for moving parts. U-Tubes should not rattle, and all parts should be firm.
-  **WARNING:** Your bike will handle differently when hauling cargo. Ride cautiously and never perform stunts (like riding without hands).
-  **WARNING:** Always make sure your cargo is secured by straps rated over the weight of your cargo, and attach warning flags to any cargo extending behind or in front of your bike.

View the Xtracycle Owner's Manual at xtracycle.com/support for additional safety guidelines when riding with cargo.