



# UteDeck

*Welcome to the Xtracycle family of accessories for your longtail.*



**x 6**

**INCLUDED HARDWARE**  
6 x 25mm M5 Stainless Bolt

## TOOLS NEEDED

- 1) 4mm allen - to remove existing deck
- 2) 3mm allen - to install UteDeck

## STEPS TO INSTALL YOUR UTEDECK

- 1) Remove existing deck and hardware
- 2) Install UteDeck as pictured using 6 x 25mm M5 Stainless Bolt

## PEAPODLT INSTALLATION NOTES

- 1) Follow included instructions with your PeaPodLT
- 2) UteDeck will take the place of FlightDeck in instructions
- 3) Unlike Xtracycle based installs of the PeaPodLT, UteDeck users will install UteDeck to bike first, then bolt PeaPodLT to UteDeck.

